## **CEILING LAMP 2162**

**DESIGNER: JOSEF FRANK** 

Josef Frank originally created Ceiling Lamp 2162 for his own company, "Haus & Garten" (House and Garden), in Vienna in the late 1920s. The lamp is designed so that the light is reflected evenly and beautifullyin the room.

ART NR:	100021 / 100022
HEIGHT EX. LIGHT SOURCE:	13 CM
HEIGHT INC. LIGHT SOURCE:	18 CM
DIAMETER:	20 CM
WEIGHT:	0,5 KG
MAX WATTAGE:	60 W
LAMP-SOCKET:	E27
CLASS OF PROTECTION:	I
IP-CODE:	IP 20
MATERIAL:	BRASS / NICKEL PLATED BRASS





HANTVERKSMÄSSIGT TILLVERKAD


## CARE INSTRUCTIONS


Svenskt Tenn's lamps are lacquered and should never be polished. Avoid contact with water as it can stain.

## **ASSEMBLY INSTRUCTIONS**

No loose parts in the package

- I. Unscrew the two side screws from the lamp cover (A). Remove the white ceiling mount (B).
- 3. Attach the ceiling mount (B) through the two screw holes onto the ceiling.
- 4. Put on the lamp cover (A). Screw on the side screws.





3.

